

# RESOL DeltaSol<sup>®</sup> BS Plus

**Mounting**

**Connection**

**Operation**

**Fault diagnostics**

**Application examples**



DeltaSol<sup>®</sup> BS Plus

US/CA  
manual

Thanks for buying a RESOL product.  
Read this manual carefully to get the best performance from this unit.

[www.resol.de](http://www.resol.de)

**Contents****Imprint****Safety regulations.....2****Technical data and overview of functions .....3****1. Installation .....4**

## 1.1 Mounting..... 4

## 1.2 Electrical Connection ..... 4

## 1.2.1 Data communication / Bus..... 5

## 1.2.2 Standard solar system..... 5

## 1.2.3 Solar system and heat exchange ..... 6

## 1.2.4 Solar system and afterheating ..... 6

## 1.2.5 Solar system and tank charge in layers ..... 7

## 1.2.6 2-tank-solar system valve logic..... 7

## 1.2.7 2-tank-Solar system pump logic ..... 8

## 1.2.8 Solar system with 2 collectors ..... 8

## 1.2.9 Solar system afterheating by solid fuel boiler ..... 9

## 1.2.10 Solar system with heating circuit return flow incr. .... 9

**2. Operation and function ..... 10**

## 2.1 Adjustment buttons .....10

## 2.2 System monitoring display .....10

## 2.2.1 Channel indication.....10

## 2.2.2 Tool bar .....10

## 2.2.3 System screen.....11

## 2.3 Blinking codes.....11

## 2.3.1 System-Screen Blinking codes.....11

## 2.3.2 LED blinking codes.....11

**3. Primary commissioning..... 12****4. Control parameter and display channels..... 13**

## 4.1 Channel overview.....13

## 4.1.1-6 Indication channels .....15

## 4.1.6-21 Adjustment channels.....16

**5. Tips for fault localization..... 21****5.1 Various .....22****6. Accessory ..... 24****Safety regulations:**

Please read the following information carefully before installing and operating the controller. In this way damage to the solar system by wrong installation will be avoided. Please observe that the mounting is adapted to the characteristics of the building, that the local regulations are respected and is conform with the technical rules.

CU 72060171 01

UL 60730-1A:2002

CSA E60730.1:2002

**Reprinting / copying**

This mounting- and operation manual including all parts is copyrighted. Another use outside the copyright requires the approval of RESOL - Elektronische Regelungen GmbH. This especially applies for copies, translations, micro films and the storage into electronic systems.

Editor: RESOL - Elektronische Regelungen GmbH


**Important notice:**

We took a lot of care over the texts and drawings of this manual and to the best of our knowledge and consent. As faults can never be excluded, please note:

Your own calculations and plans under consideration of the current norms and DIN-directions should only be basis for your projects. We don't offer a guarantee for the completeness of the drawings and texts of this manual - they only represent some examples. They can only be used on own risk. No liability is assumed for incorrect, incomplete or false information and the resulting damages.

Errors and technical changes excepted.

- System-monitoring-display
- Up to 4 temperature sensors Pt1000
- 9 basic systems selectable
- Heat balancing
- RESOL VBus®
- Function control
- Thermostat function (time controlled)
- Parameterisation and control of the system by RESOL Service Center; Software is possible
- User-friendly operation by simple handling
- Housing in outstanding design and compact dimensions, easy to install



#### Scope of delivery:

1 x DeltaSol® BS Plus

1 x accessory bag

1 x spare fuse T4A


2 x screws and dowels

4 x strain relief and screws

Additionally enclosed in the full kit:

2 x sensor FKP6

2 x sensor FRP6



#### Technical data

##### Housing:

plastic, PC-ABS and PMMA

**Protection type:** IP 20 / DIN 40050

**Ambient temp.:** 32 ... 104 °F

**Size:** 172 x 110 x 46 mm

**Mounting:** wall mounting, mounting into patch-panels is possible

**Display:** System screen for system visualisation, 16-segment display, 7-segment display, 8 symbols for system status and operating control lamp

**Operation:** by 3 pushbuttons in the front of the housing

**Functions:** Differential temperature controller with optional add-on system functions. Function control according to BAW-standards, operating hours counter for solar pump, tube collector special function, thermostat function and heat quantity balancing.

**Inputs:** for 4 temperature sensors Pt1000

**Outputs:** 2 electromechanical relays

**Bus:** RESOLVBus®

**Power supply:**

115V~


**Total power supply:**

4 (2) A 115V~



## 1. Installation

### 1.1 Mounting




**Warning!**  
Switch-off power supply before opening the housing.

This unit must only be located internally. It is not suitable for installation in hazardous locations and should not be sited near to any electromagnetic field. The controller must additionally be equipped with an all-polar gap of at least 3 mm or with a gap according to the valid installation regulations, e.g. LS-switches or fuses. Please ensure sensor cables and ac power supply are separated

1. Unscrew the cross-head screw of the cover and remove it from the housing.
2. Mark the upper fastening point on the subsurface and premount the enclosed dowel and screw.
3. Mount the housing to the upper fastening point and mark the lower fastening point on the subsurface (pitch of hole 130 mm), afterwards set the lower dowel.
4. Mount the housing to the top and fix it with the lower fastening screw.

### 1.2 Electrical connection



The power supply to the controller must only be made by an external power supply switch (last step of installation!) and the line voltage must be 115 Volt (50...60 Hz). Flexible lines are to be fixed at the housing by enclosed strain relief supports and screws.

The controller is equipped with 2 standard relays, to which the **consumers** e.g. pumps, valves etc. can be connected:

- Relay 1  
18 = conductor R1  
17 = neutral conductor N  
13 = ground clamp
- Relay 2  
16 = conductor R2  
15 = neutral conductor N  
14 = ground clamp

The **temperature sensors** (S1 up to S4) will be connected to the following terminals independently of the polarity:

- 1 / 2 = Sensor 1 (e.g. Sensor collector 1)
- 3 / 4 = Sensor 2 (e.g. Sensor tank 1)
- 5 / 6 = Sensor 3 (e.g. Sensor collector 2)
- 7 / 8 = Sensor 4 (e.g. Sensor tank 2)

The **power supply** is effected to the clamps:

- 19 = neutral conductor N
- 20 = conductor L
- 12 = ground clamp




Dangerous voltage on contact!



Electrostatic discharge can lead to damages of electronic components!

### 1.2.1 Data communication/ Bus




The controller comes with a RESOL VBus® for data communication and energy supply of external modules. The connection is effected with optional polarity at the clamps marked with „VBus®“. Via this data Bus you can install one or more RESOL VBus® modules, e.g.:

- RESOL heat quant. measurement module WMZ-M1
- RESOL large display GA3
- RESOL Data logger, DL1
- RESOL Data teleindication, DFA2

Additionally, the controller can be connected to the PC with the help of a RESOL RS-COM adapter. With the **RESOL Service Center Software (RCS)** the controller parameters can be changed, measurements can be read out, processed and visualised. The software enables an easy function control and adjustment of the system. A light Version of the software can be downloaded from [www.resol.de](http://www.resol.de) for free.

### 1.2.2 Allocation of clamps for system 1




**Standard solar system** with 1 tank, 1 pump and 3 sensors. Sensor S4 / TRF can optionally be used for heat quantity balancing.

Symbol	Specification
S1	Collector sensor
S2	Tank sensor below
S3	Tank sensor at the top (optionally)
S4 / TRF	Sensor for heat quantity measurement (optionally)
R1	Solar pump


1.2.3 Allocation of clamps for system 2

Solar system and heat exchange with an existing tank with 1 tank, 4 sensors and 2 pumps.




1.2.4 Allocation of clamps for system 3


Solar system and after-heating with 1 tank, 3 sensors and after-heating. Sensor S4 / TRF can optionally be used for heat quantity balancing.



1.2.5 Allocation of clamps for system 4




**Solar system and tank charge in layers** with 1 tank, 3 sensors, 1 solar pump and 3-way-valve for tank charge in layers. Sensor S4 / TRF can optionally be used for heat quantity balancing.




Symbol	Specification
S1	Collector sensor
S2	Tank sensor lower
S3	Tank sensor at the top
S4 / TRF	Sensor for heat quantity balancing (optionally)
R1	Solar pump
R2	3-way-valve

1.2.6 Allocation of clamps for system 5




**2-tank-solar system with valve logic** with 2 tanks, 3 sensors, 1 solar pump and 1 3-way-valve. Sensor S4 / TRF can optionally be used for heat quantity balancing.



Symbol	Specification
S1	Collector sensor
S2	Tank sensor 1
S3	Tank sensor 2
S4 / TRF	Sensor for heat quantity balancing (optionally)
R1	Solar pump
R2	3-way-valve


1.2.6 Allocation of clamps for system 6

2-tank-solar system with pump logic with 2 tanks, 3 sensors and 2 solar pumps.



1.2.7Allocation of clamps for system 7


Solar system with east-west collectors, 1 tank, 3 sensors and 2 solar pumps.






1.2.8 Allocation of clamps for system 8

Solar system with after-heating by solid fuel boiler with 1 tank, 4 sensors, 1 solar pump and 1 pump for after-heating.




1.2.9 Allocation of clamps for system 9

Solar system and heating circuit reverse raising with 1 tank, 4 sensors, 1 solar pump and 1 3-way-valve for heating circuit reverse raising.



2. Opeartion and function

2.1 Pushbuttons for adjustment




The controller is operated by 3 pushbuttons below the display. The forward-key (1) is used for scrolling forward through the indication menu or to increase the adjustment values. The backwards-key (2) is accordingly used for the reverse function.

For adjustment of last indication channel, keep button 1 pressed for 3 seconds. If an **adjustment value** is shown on the display, **SET** is indicated. In this case you can press the key „Set“ (3) in order to change into input mode.

Select a channel by keys 1 and 2  
Shortly press key 3, so that **SET** is blinking.  
Adjust the value by keys 1 and 2  
Shortly press key 3, so that **SET** permanently appears, the adjusted value is now saved.

2.2 System monitoring display



The system monitoring display consists of 3 blocks: **indication of the channel**, **tool bar** and **system screen** (active system scheme).

2.2.1 Channel indication



The **indication channel** consists of two lines. The upper line is an alphanumeric 16-segment indication in which mainly the channel names / menu items are shown. In the lower 7-segment indication, the channel values and the adjustment parameters are indicated.  
Temperatures and temperature differences are indicated in °F / °C or Ra / K.


2.2.2 Tool bar



The additional symbols of the **tool bar** indicate the current system status.



Symbol	standard	blinking
ⓘ	relay 1 active	
Ⓜ	relay 2 active	
☀	maximum tank limitation active / maximum tank temperature exceeded	collector cooling function or reccoling function active
❄	antifreeze- function activated	collector minimum limitation or antifreeze function active
⚠		collector security shutdown or tank securtiy shutdown active
⚠ + 🔧		sensor defect
⚠ + 🖐		manual operation active
SET		an adjustment channel is changed SET-mode

### 2.2.3 System screen




System Screen only

The system screen (active system scheme) shows the schemes selected on the controller. It consists of several system component symbols, which are - depending on the current status of the system - either flashing, permanently shown or hidden.



**Collectors**  
with collector sensor



**Tanks 1 and 2**  
with heat-exchanger



**3-way-valve**  
The flow direction or the current breaking capacity is always shown.



**Temperature sensor**



**Heating circuit**



**Pump**



**Afterheating**  
with burner symbol

## 2.3 Blinking codes

### 2.3.1 System screen blinking codes


- Pumps are blinking during starting phase
- Sensors are blinking if the respective sensor-indication channel is selected.
- Sensors are quickly blinking in case of sensor defect.
- Burner symbol is blinking if after-heating is activated

### 2.3.2 LED blinking codes

- Constantly green: everything all right  
 Red/green blinking: initialisation phase  
 manual operation  
 Red blinking: sensor defect  
 (sensor symbol is quickly blinking)

### 3. Primary commissioning

For primary commissioning the system scheme has to be adjusted first



1. AC power supply must be activated at first. The controller passes an initialisation phase during which the operating control lamp is blinking red and green. After having finished the initialisation, the controller is in automatic operation with factory settings. The preadjusted system scheme is Arr 1.


2. Clock time adjustment in channel TIME. By pressing the **SET** button once you can adjust hours, pressing it once again the minutes. The time can be adjusted by buttons 1 and 2 and saved by pressing the **SET** button.

3. - select adjustment channel Arr


- change into **SET**-mode (see 2.1)

- adjustment are saved by pressing button **SET**


Now the controller is ready for operation and should enable an optimum operation of the solar system with the factory settings.




Arr 1




Arr 2




Arr 3




Arr 4




Arr 5




Arr 6



Arr 7



Arr 8



Arr 9

#### System survey:

Arr 1 : standard solar system

Arr 2 : solar system with heat exchange

Arr 3 : solar system with after-heating

Arr 4 : solar system with tank charge in layers

Arr 5 : 2-tank solar system with valve logic

Arr 6 : 2-tank solar system with pump logic

Arr 7 : solar system with 2 collectors and 1 tank

Arr 8 : solar system with after-heating by solid hot fuel boilers

Arr 9 : solar system with heating circuit reverse raising

## 4. Control parameter and indication channels

### 4.1 Channel-overview

#### Legend:

x

Corresponding channel is available.

x\*

Corresponding channel is available if the appropriate option is activated.

#### Please note:

S3 and S4 are only indicated in case of sensors connected

①

Corresponding channel is only available if the option heat quantity measurement is **activated** (OHQM).

②

Corresponding channel is only available if the option heat quantity measurement is **deactivated** (OHQM).

MEDT

The channel antifreeze content (MED%) is only shown if **the antifreeze is not water or Tyfocor LS / G-LS (MEDT 0 or 3)**. Adjustments concerning the antifreeze content will only make sense if the antifreeze is used in the solar circuit.

Channel	Arr									Specification	Page
	1	2	3	4	5	6	7	8	9		
COL	x	x	x	x	x	x		x	x	Temperature collector 1	15
COL 1							x			Temperature collector 1	15
TST	x						x			Temperature tank 1	15
TSTU			x	x				x	x	Temperature tank 1 below	15
TST1		x			x	x				Temperature tank 1 below	15
TSTO		x	x	x				x	x	Temperature tank 1 at the top	15
TST2		x			x	x				Temperature tank 2 below	15
TFSB								x		Temperature solid hot fuel boiler	15
TRET									x	Temperature heating circuit	15
COL2							x			Temperature collector 2	15
S3	x									Temperature sensor 3	15
TRF	①		①							Temperature return sensor	15
S4	②		②	②	②	x	x			Temperature sensor 4	15
hP	x			x	x				x	Operating hours relay 1	16
h P1		x	x			x	x	x		Operating hours relay 1	16
h P2		x	x			x	x	x		Operating hours relay 2	16
kWh	①		①	①	①					Heat quantity kWh	16
MWh	①		①	①	①					Heat quantity MWh	16
time	x									Time	15
Arr	1-9									System	12
DT O	x	x	x				x	x	x	Switch-on temperature diff	17
DT1O				x	x	x				Switch-on temperature diff 1	17
DT F	x	x	x				x	x	x	Switch-off temperature diff 1	17
DT1F				x	x	x				Switch-off temperature difference	17
S MX	x	x	x				x	x	x	Maximum temperature tank 1	17
S1 MX				x	x	x				Maximum temperature tank 1	17
DT2O				x	x	x				Switch-on temperature difference 2	17
DT2F				x	x	x				Switch-off temperature difference 2	17
S2MX				x	x	x				Maximum temperature tank 2	17
EM	x	x	x	x	x	x		x	x	emergency temperature collector 1	18
EM1							x			emergency temperature collector 1	18

Channel	Arr									Specification	Page
	1	2	3	4	5	6	7	8	9		
OCX	x	x	x	x	x	x		x	x	option collector cooling collector 1	18
OCX1							x			option collector cooling collector 1	18
CMX	x*	x*	x*	x*	x*	x*		x*	x*	maximum temperature collector 1	18
CMX1							x*			maximum temperature collector 1	18
OKN	x	x	x	x	x	x		x	x	option minimum limitation collector 1	18
OKN1							x			option minimum limitation collector 1	18
CMN	x*	x*	x*	x*	x*	x*		x*	x*	minimum temperature collector 1	18
CMN1							x*			minimum temperature collector 1	18
OCF	x	x	x	x	x	x		x	x	option antifreeze collector 1	18
OCF1							x			option antifreeze collector 1	18
CFR	x*	x*	x*	x*	x*	x*		x*	x*	antifreeze temperature collector 1	18
CFR1							x*			antifreeze temperature collector 1	18
EM2							x			emergency temperature collector 2	18
OCX2							x			option collector cooling collector 2	18
KMX2							x*			maximum temperature collector 2	18
OCN2							x			option minimum limitation collector 2	18
CMN2							x*			minimum temperature collector 2	18
OCF2							x			option antifreeze collector 2	18
CFR2							x*			antifreeze temperature collector 2	18
PRIO				x	x	x				priority	19
tST				x	x	x				stop time	19
tRUN				x	x	x				Circulation time	19
OREC	x	x	x	x	x	x	x	x	x	option recolling	19
OTC	x	x	x	x	x	x	x	x	x	option tube collector	19
DT3O		x						x		switch-on temperature difference 3	17
DT3F		x						x		switch-off temperature difference 3	17
MX3O		x						x		switch-on threshold for maximum temp.	17
MX3F		x						x		switch-off threshold for maximum temp.	17
MN3O		x						x		switch-on threshold for minimum temp.	17
MN3F		x						x		switch-off threshold for minimum temp.	17
AH O			x							switch-on temp. for thermostat 1	20
AH F			x							switch-off temp. for thermostat 1	20
OHQM	x		x	x	x					option VMZ	16
FMAX	①		①	①	①					maximum flow	16
MEDT	①		①	①	①					antifreeze type	16
MED%	MEDT		MEDT	MEDT	MEDT					antifreeze content	16
t1 on			x							Switch on time 1 thermostat	20
t1 off			x							Switch off time 1 thermostat	20
t2 on			x							Switch on time 2 thermostat	20
t2 off			x							Switch off time 2 thermostat	20
t3 on			x							Switch on time 3 thermostat	20
t3 off			x							Switch off time 3 thermostat	20
HND1	x	x	x	x	x	x	x	x	x	manual operation relay 1	20
HND2	x	x	x	x	x	x	x	x	x	manual operation relay 2	20
LANG	x	x	x	x	x	x	x	x	x	Language	20
UNIT	x	x	x	x	x	x	x	x	x	Change over °FAH / °CEL	20
PROG	XX.XX									program number	
VERS	X.XX									version number	

#### 4.1.1 Indication of collector temperatures

##### COL, COL1, COL2:

Collector temperature  
display range: -40...+480 °F




Shows the current collector temperature.

- COL : collector temperature (1-collector-system)
- COL1: collector temperature 1
- COL2: collector temperature 2

#### 4.1.2 Indication of tank temperatures

##### TST, TSTL, TSTU, TST1, TST2:

Tank temperatures  
Display range: -40...+480 °F



Shows the current tank temperature.


- TST : tank temperature (1-tank-system)
- TSTL : tank temperature lower
- TSTU : tank temperature above
- TST1 : temperature tank 1
- TST2 : temperature tank 2

#### 4.1.3 Indication of sensor 3 and sensor 4

##### S3, S4:

##### S3, S4:

Sensor temperatures  
Display range: -40...+480 °F



Shows the current temperature of the corresponding additional sensor (without control function).

- S3 : temperature sensor 3
- S4 : temperature sensor 4


##### Please note:

S3 and S4 are only shown if the temperature sensors are connected.

#### 4.1.4 Indication of other temperatures

##### TFSB, TRET, TRF:


other measured temperatures  
Display range: -40...+480 °F



Shows the current temperature of the corresponding sensor.

- TFSB : temperature solid fuel boiler
- TRET : temperature heating reverse raising
- TRF : temperature return flow

#### 4.1.5 Time




In this channel the current time is indicated.

By pressing button **SET** for 2 seconds the hours, by pressing it again the minutes are displayed blinking. The time can be set by buttons 1 and 2 and saved by pressing the **SET** button.

#### 4.1.6 Operating hours counter

**h P / h P1 / h P2:**  
operating hours counter  
Indication channel



The operating hours counter adds up the solar operating hours of the respective relay (**h P / h P1 / h P2**). Full hours are shown on the display.

After the operating hours are added up, they can be reset. As soon as one operating hours channel is selected, symbol **SET** is permanently shown on the display. The button SET (3) must be pressed for approx. 2 seconds in order to get back into the RESET-mode of the counter. The display-symbol **SET** is blinking and the operating hours will be set to 0. In order to finish the RESET-procedure, the button **SET** must be pressed in order to confirm the data.

In order to interrupt the RESET-procedure, don't press any button for about 5 seconds. The controller returns automatically into the indication mode.

#### 4.1.7 Heat quantity balancing

**OHQM:** Heat quantity measurement  
Adjustment range: OFF...ON  
Factory setting: OFF



A heat quantity balancing is possible for the basic systems (Arr) 1, 3, 4 and 5 in conjunction with a flowmeter. You just have to activate the option heat quantity balancing in channel **OHQM**.

**FMAX:** Volume flow in l/min  
Adjustment range 0...20  
in steps of 0,1  
Factory setting 6,0



The volume flow readable at the flowmeter (l/min) must be adjusted in the channel **FMAX**. Antifreeze type and concentration of the heat transfer medium are indicated on channels **MEDT** and **MED%**.

**MEDT:** antifreeze  
Adjustment range 0...3  
Factory setting 1



**Type of antifreeze:**  
0 : water  
1 : propylene glycol  
2 : ethylene glycol  
3 : Tyfocor® LS / G-LS

**MED%:** Concentration of antifreeze in (Vol-) %  
MED% is blinded out by MEDT 0 and 3.  
Adjustment range 20...70  
Factory setting 45



**kWh/MWh:** Heat quantity in kWh / MWh  
Display channel



The heat quantity transported is measured by the indication of the volume flow and the reference sensor of feed flow S1 and return flow T-. It is shown in kWh-parts in the indication channel **kWh** and in MWh-parts in the indication channel **MWh**. The sum of both channels form the total heat output.

The heat quantity added up can be reset. As soon as one of the display channels of the heat quantity is selected, symbol **SET** is permanently shown on the display. The SET (3) button must be pressed for approx. 2 seconds in order to get back into the RESET-mode of the counter. The display-symbol **SET** is blinking and the value for heat quantity will be set to 0. In order to finish the RESET-procedure, the button **SET** must be pressed in order to confirm the data.

In order to interrupt the RESET-procedure, no button should be pressed for about 5 seconds. The controller returns automatically into the indication mode.



#### 4.1.8 ΔT-regulation

##### DT F / DT1F / DT2F / DT3F:

Switch on temperature diff.

Adjustment range 2,0...40,0°Ra

Factory setting 12,0°Ra




##### DT O / DT1O / DT2O /

##### DT3O:

Switch-off temperature diff.

Adjustment range 1,0...39,0°Ra

Factory setting 8,0°Ra



**Please note:** Switch-on temperature difference DO must be at least 2 °Ra higher than the switch-off temperature-difference DF.

First the controller works in the same way as a standard differential controller. If the switch-on difference (**DT F** / **DT1F** / **DT2F**) is reached, the pump is activated. If the adjusted switch-off temperature is underrun (**DT O** / **DT1O** / **DT2O**), the controller switches-off.

**DT F** and **DT S** are locked against each other. **DT S** has to be at least by 0,5°Ra above **DT F**.


#### 4.1.9 Tank maximum temperature

##### S MX / S1MX / S2MX:

Maximum tank temp.

Adjustment range -40...+480°F

Factory setting -140°F



If the adjusted maximum temperature is exceeded, a further loading of the tank is stopped so that a damaging overheating can be avoided. If the maximum tank temperature is exceeded, symbol is shown on the display.

**Please note:** The controller is equipped with a security-switch-off of the tank, which avoids a further loading of the tank if 295°F is reached at the tank.

#### 4.1.10 ΔT-controller (solid fuel boiler and heat exchange)

##### Maximum temperature limitation

##### MX3O / MX3F:



Maximum temperature limitation

Adjustment range 30...205°F

Factory setting

MX3O 140°F

MX3F 136°F



The controller is equipped with an independent temperature differential regulation for which minimum and maximum temperature limitations as well as corresponding switch-on and -off temperatures can be separately adjusted. Only possible for Arr = 2 and 8 (e.g. for solid fuel boilers or heat exchange regulation).

If the adjusted value **MX3O** is exceeded, relay 2 will be deactivated. When falling below **MX3F**, the relay will be switched on again.

Reference sensor:

S3 by Arr 8 (TSTU)

S4 by Arr 2 (TST2)

Is the adjusted value **MN3O** underrun, relay 2 will be deactivated. By falling below **MN3F**, the relay will be switched on again.

Reference sensor:

S4 by Arr 8 (TFSB)

S3 by Arr 2 (TSTU)

Both switch on- and switch off temperature differences **DT3F** and **DT3O** apply parallelly for the maximal- and minimal temperature limit.

##### Minimum temperature limitation

##### MN3O / MN3F:

Minimum temperature limitation

Adjustment range 30...195°F

Factory setting:

Arr = 2

MN3O 40°F

MN3F 50°F

Arr = 8

MN3O 140°F

MN3F 150°F



#### 4.1.11 Collector temperature limitation Emergency shut down of the collector

##### EM / EM1 / EM2:

temperature limitation collector  
Adjustment range 230...400°F  
Factory setting 285°F




If the adjusted collector limit temperature (**EM** / **EM1** / **EM2**) is exceeded the solar pump (R1/R2) is deactivated in order to avoid a damaging overheating of the solar components (collector emergency shutdown). The factory setting for the temperature limitation is 285°F - it can be changed within the adjustment range of 230...400°F. Symbol  $\triangle$  is shown on the display (blinking).

#### 4.1.12 System cooling

##### OCX / OCX1 / OCX2:

Option System cooling  
Adjustment range OFF...ON  
Factory setting OFF



##### CMX / CMX1 / CMX2:

collector maximum temperature  
Adjustment range 210...380°F  
Factory setting 250°F



If the adjusted maximum tank temperature is reached, the solar system switches-off. If now the collector temperature rises to the adjusted maximum collector temperature (**CMX** / **CMX1** / **CMX2**), the solar pump remains activated until this temperature limitation value is again underrun. The tank temperature might continue to rise (subordinated active maximum tank temperature), but only up to 400°F (emergency shutdown of the tank). If the tank temperature is higher than the maximum tank temperature (**S MX** / **S1MX** / **S2MX**) and the collector temperature is by at least 10°RA lower than the tank temperature, the solar system remains activated until the tank is cooled down again by the collector and the tubes below the adjusted maximum temperature (**S MX** / **S1MX** / **S2MX**) (only by activated **OREC** function).

In case of an activated system  $\star$  is shown on the display (blinking). Due to the cooling function, the solar system can be kept operable for a longer period on hot summer days and a thermal release of the collector and the heat transfer medium is ensured as well.

#### 4.1.13 Option collector minimum limitation

##### OCN / OCN1 / OCN2:

collector minimum limitation  
OFF / ON  
Factory setting OFF



##### CMN / CMN1 / CMN2:

col. minimum temperature  
Adjustment range 50...195°F  
Factory setting 50°F



The minimum collector temperature is a minimum switching temperature which must be exceeded so that the solar pump (R1/R2) is switched-on. The minimum temperature shall avoid a steady starting-up of the solar pump (or solid fuel boiler charging pumps) for low collector temperatures. If the minimum temperature is underrun,  $\star$  is shown on the display (blinking).

#### 4.1.14 Option antifreeze

##### OCF / OCF1 / OCF2:

antifreeze function  
Adjustment range OFF / ON  
Factory setting OFF



##### CFR / CFR1 / CFR2:

antifreeze temperature  
Adjustment range 15...50°F  
Factory setting 40°F



The antifreeze function activates the loading circuit between collector and tank if the adjusted antifreeze function is underrun in order to protect the medium against freezing or „thickening“. If the adjusted frost protection temperature is exceeded by 2°F, the loading circuit will be deactivated.

##### Please note:

As there is only a limited heat quantity of the tank available for this function, the antifreeze function should only be used in regions with few days of temperatures around freezing point.

#### 4.1.15 Oscillating charge

Respective adjustment values:

priority [PRIO]

oscillating break-time [tST]

oscillating charge-time [tRUN]

**Factory setting**

(1 / Arr 5,6) (2 / Arr 4)

2 min.

15 min.

**Adjustment range**

0-2

1-30 min.

1-30 min.


Die DeltaSol® BS Plus priority logic

priority:



The above-mentioned options and parameters only have a meaning in multi-tank systems (system Arr = 4, 5, 6). If **priority 0** is adjusted, the tanks which show a temperature difference towards the collector are loaded in numerical order (tank 1 or tank 2). Usually only one tank is loaded at this point. For Arr= 5, 6 parallel loading is also possible.

Oscillating break time / oscillating charge time / collector rising temperature



The controller checks the tanks regarding loading facilities (switch-on difference). If the priority tank cannot be loaded, the lower-ranking tank is checked. If the lower-ranking tank can be charged this is effected by the so-called „oscillating charge time“ (**tRUN**). When the oscillating charge time is over the loading is stopped. The controller regulates the increase of the collector temperature. If it increases by the collector rising temperature ( $\Delta T_{\text{Col}} 4^{\circ}\text{Ra}$ , fixed software value), the expired break time is again reset to zero and the oscillating break time starts again. If the switch-on conditions of the priority tank are not reached, the loading of the lower-ranking tank is continued. If the priority switch has reached its maximum temperature, the oscillating charge is not effected.

#### 4.1.16 Recooling function

**OREC:**

option recooling

adjustment range OFF...ON

Factory setting: OFF



If the adjustem maximum tank temperaute (**S MX, S1MX, S2MX**) is reached, the solar pump remains activated in order to avoid an overheating of the collector. The tank temperature might continue to increase but only up to 205°F (emergency shutdown of the tank).

In the evening the solar system continues running until the tank is cooled down to the adjusted maximum tank temperature via collector and pipes.

#### 4.1.17 Tube collector special function

**OTC:**

Tube collector special function

Adjustment range: OFF...ON



Factory setting: OFF




If the controller measures an increase of  $4^{\circ}\text{Ra}$  compared to the collector temperature stored at last, the solar pump is switched-on to 100 % for about 30 seconds. After the expiration of the solar pump runtime the current collector temperature is stored as a new reference value. If the measured temperature (new reference value) is again exceeded by  $4^{\circ}\text{Ra}$ , the solar pump again switches-on for 30 seconds. If the switch-on difference between collector and tank is again exceeded during the runtime of the solar pump or the standstill of the system, the controller automatically switches over to solar charging.

If the collector temperature drops by  $4^{\circ}\text{Ra}$  during standstill, the switch-on value for the special tube collector function will be recalculated.

## 4.1.18 Thermostat function (Arr = 3)

**AH O:**


Thermostat-switch-on temperature  
Adjustment range 30...205°F  
Factory setting 105°F

**AH F:**

Thermostat-switch-off temperature  
Adjustment range 30...205°F  
Factory setting 115°F

The thermostat function works independently from the solar operation and can e.g. be used for the use of surplus energy or after-heating.

- **AH O < AH F**  
the thermostat function is used for after-heating
- **AH O > AH F**  
the thermostat function is used for use of surplus energy

Symbol  will be shown on the display if the second relay output is activated.

**t1 E, t2 E, t3 E:**

Thermostat switch-on time  
Adjustment range:  
00:00 ...23:45  
Factory setting: 00:00

**t1 A, t2 A, t3 A:**

Thermostat switch-off time  
Adjustment range:  
00:00 ...23:45  
Factory setting: 00:00


In order to block the thermostat function for a certain time span, there are 3 time frames t1 ...t3. If the function should be activated only between e.g. 6:00 and 9:00, 6:00 should be set for **t1 E** and 9:00 should be set for **t1 A**. The factory setting for the thermostat function is in continuous operation.

If all time frames should stop at 00:00 o'clock, the thermostat function is continuously in operation (factory setting).

## 4.1.19 Operating mode

**HND1/HND2:**





Operating mode  
Adjustment range:  
OFF, AUTO, ON  
Factory setting: AUTO



For control- and service works the operating mode of the controller can be manually adjusted by selecting the adjustment value MM in which the following adjustments can be made:

• **HND1 / HND2**

Operating mode

- OFF : relay off  (blinking) + 
- AUTO : relay in automatic operation
- ON : relay on  (blinking) + 

## 4.1.20 Language

**LANG:**

Adjustment of language  
Adjustment range: dE, En, It, Fr  
Factory setting: En




The menu language can be adjusted in this channel.

- dE : German
- En : English
- It : Italiano
- Fr : French

## 4.1.21 Unit

**UNIT:**


Adjustment of unit  
Adjustment range: FAH, °C  
Factory setting: FAH




The menu unit can be adjusted:

- °FAH
- °CEL

## 5. Tips for fault localization



If a malfunction occurs, it will be indicated on the display of the controller:



Operating control lamp flashes red. On the display the symbols and appear.

Sensor defect. An error code is shown on the relevant sensor indication channel instead of a temperature.

888.8

- 88.8

Line break. Check the line.

Short-circuit. Check the line.

Pt1000-temperature sensors pinched off can be checked with an ohmmeter. In the following the resistance values corresponding to different temperatures are listed.

°F	Ω	°F	Ω
14	961	131	1213
23	980	140	1232
32	1000	149	1252
41	1019	158	1271
50	1039	167	1290
59	1058	176	1309
68	1078	185	1328
77	1097	194	1347
86	1117	203	1366
95	1136	212	1385
104	1155	221	1404
113	1175	230	1423
122	1194	239	1442

Resistance values of the Pt1000-sensors

Operating control lamp off


Check the power supply

o.k.


The can fuse of the controller is defective. It can be replaced after removal of the front cover (spare fuse is enclosed in the accessory bag).

## 5.1 Various:


Pump is overheated, but no heat transfer from collector to the tank, feed flow and return flow are equally warm, possibly also bubble in the tubes




Pump starts for a short moment, switches-on/off repeatedly





Pump starts up very late and stops working soon.



The temperature difference between tank and collector increases enormously during operation; the collector circuit cannot dissipate the heat.







## 6. Accessory

### Sensors

Our product range comprises high-precision platin temperature sensors, flatscrew sensors, ambient temperature sensors, indoor temperature sensors, cylindrical clip-on sensors and irradiation sensors, also to be used as complete sensors with sensor pocket.



### Overvoltage protection

We highly recommend to install the RESOL overvoltage protection in order to avoid overvoltage damages at the collector (e.g. by lightning).



### Flowmeter

In order to effect a heat quantity balancing, you need a flowmeter for measuring the volume flow in your system.



### RS-COM Adapter

By means of a RS-COM Adapters the controller can be connected to a PC.



### RESOL Service Center Software

The controller can be visualized and configured comfortably by PC with the RESOL Service Center Software.

A light version of the software can be downloaded from [www.resol.de](http://www.resol.de) for free.

---

### RESOL - Elektronische Regelungen GmbH

Heiskampstraße 10  
D - 45527 Hattingen

Tel.: +49 (0) 23 24 / 96 48 - 0  
Fax: +49 (0) 23 24 / 96 48 - 55

[www.resol.de](http://www.resol.de)  
[info@resol.de](mailto:info@resol.de)

### Distributed by:

### Comments:

The design and the specifications can be changed without advance notice.  
The illustrations can differ from the production model.