


WG20 Grinder Pump

SAFETY, INSTALLATION AND SER-
VICING INSTRUCTINS FOR MYERS
WG20 GRINDER PUMP



13800A764
Bag #18812A003

Myers®
Pentair Pump Group

MUST BE INSTALLED BY EXPERIENCED PROFESSIONALS ONLY

CAUTION: READ THESE SAFETY WARNINGS FIRST BEFORE INSTALLATION, SERVICING, OR OPERATING ANY PUMP. THESE INSTRUCTIONS ARE WRITTEN WITH THE UNDERSTANDING THAT THE INDIVIDUAL(S) HAVE EXPERIENCE IN BUILDING WET WELLS AND INSTALLING BASINS, GRINDER PUMPS AND PUMPING EQUIPMENT.

NOTE: Models with third party approval(s) are clearly marked on individual pump name-plates.

WARNING! Risk of electrical shock. To reduce risk of electrical shock, see instruction manual for installation.

DO NOT REMOVE CORD AND STRAIN RELIEF.

On three phase pumps only "Motor Protection" must be provided by the installer. All three phase pumps must be installed with magnetic starters having three leg overload protection in accordance with the national electrical code. For duplex installations both pump motors must have separate overload protection.

WARNING: Only qualified persons shall conduct services and installations of this pump. The pump must be wired by a qualified electrician, using an approved starter box and switching device.

Pumps with seal leak detectors must be connected to the proper control circuitry. See instructions manual.

DANGER! HAZARDOUS MOVING PARTS. To reduce risk of injury disconnect power before servicing. Never put fingers near grinder impeller or in pump inlet when pump cord is connected or pump is operating.

FOR USE WITH MAXIMUM 140°F LIQUID ACCEPTABLE FOR OUTDOOR USE.

DANGER! In the initial installation, before sewage is admitted to the basin, there is no danger on entering the basin, but after sewage has been in the basin there is **DANGER. SEWAGE WATER GIVES OFF METHANE AND HYDROGEN SULFIDE GASSES, BOTH OF WHICH ARE HIGHLY**

POISONOUS. A BREATHING DEVICE MAY BE REQUIRED. NEVER ENTER BASIN UNLESS COVER IS OPEN AND AN OUTSIDE BLOWER IS USED TO FORCE FRESH AIR INTO THE BASIN. ALSO, THE WORKER IN THE BASIN MUST WEAR A HARNESS ATTACHED TO THE SURFACE SO THAT HE CAN BE PULLED OUT IN CASE OF ASPHYXIATION. NEVER WORK ALONE!

WARNING!

- ▲ **Do not** exceed working load limit of lifting rope or chain. Do not use lifting rope or chain where failure could result in loss of life.
- ▲ **Examine** all lifting devices, rope or chain for damage before and after each lift.
- ▲ **Do not** use any lifting devices that are not rated for and designed to lift the weights involved with these pumps.
- ▲ **Do not** install or remove pump with person(s) in basin.

GENERAL

1. Most accidents can be avoided by using **COMMON SENSE.**
2. Read the operation and maintenance instructions manual supplied with the pump.
3. **DO NOT** wear loose clothing that can become entangled in the impeller or other moving parts.
4. This pump is designed to handle materials which could cause illness or disease through direct exposure.

Wear and use protective clothing when working on the pump or piping.

ELECTRICAL

1. To reduce the risk of electrical shock, pump must be properly grounded in accordance with the National Electric Code and all applicable state and local codes and ordinances.
2. To reduce risk of electrical shock, disconnect the pump from the power source before handling or servicing.
3. Any wiring to be done on pump should be done by a qualified electrician.
4. **NEVER**, operate a pump with a power cord that has frayed or brittle insulation.

5. **NEVER** LET CORDS or plugs lay in water.
6. **NEVER** handle connected power cords with wet hands.

PUMPS

1. Pump builds up heat and pressure during operating, allow time for pump to cool before handling or servicing.
2. Only qualified personnel should install, operate or repair pump.
3. Keep clear of suction and discharge openings. **DO NOT** insert fingers in pump with power connected.
4. **DO NOT** pump hazardous material not recommended for pump (flammable, caustic, etc.).
5. Make sure lifting devices are securely fastened each time before lifting pump.
6. **DO NOT LIFT PUMP BY THE POWER CORD.**
7. **DO NOT** exceed manufacturer's recommendation for maximum performance, as this could cause the motor to overheat.
8. Secure the pump in its operating position so it cannot tip over, fall or slide.
9. Keep hands and feet away from impeller when power is connected.
10. Submersible grinder pumps are not approved for use in swimming pools, recreational water installations, decorative fountains or any installation where human contact with the pumped fluid is common.
11. **DO NOT** pump without safety devices in place.
12. For hazardous locations, use pumps that are listed and classified for such locations.
13. **DO NOT** use non-explosion proof rated pumps in locations considered hazardous in accordance with the National Electrical Code, ANSI/NFPA 70-1993.
14. Tank venting plumbing code.

IMPORTANT! F. E. Myers is not responsible for losses, injury or death resulting from failure to observe these safety precautions, misuse or abuse of pumps or equipment.

CONTROL PANELS

All Myers control panels used on these grinders are UL listed and CSA certified. Control panels mounted directly to the basin used

outdoors are UL listed and CSA certified waterproof.

If intrinsically safe controls used in hazardous locations are required, Myers can furnish a UL listed or CSA certified panel. Otherwise the installer must obtain a source for the panel required.

LEVEL SENSING CONTROLS

Intrinsically-safe type float controls are recommended for all applications and required for explosion-proof service. An intrinsically safe control panel relay will limit the current and voltage to the level controls. A Myers control panel can be supplied with this type circuitry.

The float level controls maintain the basin sewage water level by controlling pump turn-on and turnoff level.

1. The lower turnoff control should be set so that the pump stops at approximately the top of the pump.
2. The upper turn-on control should be set above the lower turnoff control. The exact height between the two controls is determined by the number of pump starts desired and the depth of the basin. A maximum of 10 starts per hour should not be exceeded.
3. The override control is set at a specified height above the upper turn-on control.
4. The alarm control is set about 6" to 12" above the override control.
5. No control should be set above the inlet inverts.

JUNCTION BOXES

If a junction box is used in a hazardous location, it must be an explosion-proof approved type with explosion-proof cord connectors. Wires from the junction box must pass through an explosion-proof seal connector.

CAUTION: No persons should be in the basin when pump is lowered into position! **DO NOT** lift pump in a manner where any failure could result in loss of life.

AIR VENTING

Air tends to trap in the pump volute when water raises in the sump or when the pump is lowered into water after service. To vent off this air, a small hole is drilled into the pump volute. Be sure this vent hole is clean after any service work on pump.

PUMP MODELS — This WG20 Grinder Pump is made in one model only for use with single phase and three phase power. Motor rating is 2 HP, 3540 RPM, 60 Hz. Also can be used for 50 Hz. operation. Single phase is for 230 and 208 volt and three phase for 200, 230, 460, 575 volts.

PACKAGING — Each pump with 15 feet of power cord is packaged separately in carton that is marked with Model Number and Engineering Number. Longer cords are available for special jobs.

INSTRUCTIONS — These instructions cover only the pump. Separate instructions for the electrical control panel and basin packaged system are included with those items.

DESCRIPTION OF PUMP — Figure 1 shows cut-away drawing of pump with parts called out. This pump is intended to grind and pump all normal sewage for home or commercial use. It will also handle reasonable quantities of disposable diapers, sanitary napkins, paper towels, rubber material, plastic, string, cigarette butts and other material not normally found in sewage.

FIG. 1




FIG. 1

Pump is of heavy duty construction and submersible type for long life when pumping ground sewage. Motor is capacitor start, capacitor run for single phase. Capacitors and start relay are mounted in electrical control box.

Pump has two oil filled chambers, one for motor and ball bearings and one for seals.

For long life, water must be kept out of motor chamber and this is accomplished by using two seals. The lower seal above impeller acts as buffer for upper seal that seals oil in the motor chamber. If lower seal leaks for any reason and water enters seal chamber, an electrode senses this water and a red signal light comes on at control panel indicating motor must be serviced before upper seal fails.

A heat sensor is attached to stator winding to sense any abnormal heat. If motor temperature for any cause rises above 221°F. the pump is immediately stopped and will not restart until motor cools to safe temperature.

PUMP CORDS — Each pump has two cords. The Power cord contains 4 conductors and the control cord has 5 conductors. The larger of the two cords is the power cord and the smaller cord is the control cord.

The power cord for single phase uses the color coding for start and main windings and connects to control box terminal strip black (common), white (run), and red (start). The green wire is always ground and connects to ground terminal in control box. For three phase the same 4 conductor color coded cords are used, but the black, white and red can be connected to any of the three phase terminals in the control box.

The smaller control cord for single or three phase uses black and white leads for heat sensor and connects to terminal strip in control box. The red and orange wires connect to seal failure terminals in control box and the green or ground lead connects to ground terminal in control box.

INSTALLING PUMP IN SUMP

BASIN — Complete installing and piping instructions are included with the sump basin package.

THREE PHASE — When pump is installed to operate on three phase power, pump rotation must be checked. For inside installation where control box is near the sump basin, pump can be laid on side to check rotation before installing in sump.

To check rotation turn Hand-Off-Auto switch to off position and turn on circuit breaker. Quickly turn H-O-A switch to hand position, then off. Note grinder impeller rotation. Impeller must rotate counter-clockwise. If rotation is wrong, change any two line leads to motor at control box terminals. Re-check for proper rotation. **CAUTION** — KEEP HANDS COMPLETELY AWAY FROM GRINDER IMPELLER WHEN MAKING THIS CHECK.

Where pump is installed remote from control box in outside installation a different method is used.

Set the pump in the basin and run in some water so pump can operate. Turn H-O-A switch to hand position and let pump pull water down in basin. When water reaches the bottom of pump, rotation of the water can be observed. Water should rotate in a clockwise direction if pump rotation is correct. If not correct rotation, interchange any two line leads to motor at control panel.

When replacing a pump with a new unit, rotation must be checked.

REPLACING PARTS & COMPLETE DISMANTLING OF PUMP STANDARD TOOLS REQUIRED:

1. Socket Set
2. Allen Wrench Set
3. Set Open End Wrenches
4. Plastic Hammer
5. Vise Grip Pliers

6. Large Screwdriver
7. Wire Brush
8. Three Cornered File
9. Flat File
10. Snap Ring Pliers for Outside Snap Ring
11. Crimping Pliers for Electrical Connectors
12. Arbor Press
13. Loctite #271
14. Myers Submersible Motor Oil

IMPORTANT: Before any repair work is done on pump it should be sand-blasted, if possible, to remove any deposits. After cleaning, pump should be submerged in a strong "clorox" solution for one hour before handling pump.

REPLACING GRINDER RING & GRINDER IMPELLER ONLY

1. Hold impeller from moving by placing small allen wrench or screwdriver in shredding ring slot and remove socket head screw and washer from pump shaft. See figure 2.




FIG. 2

2. Remove three screws from grinder ring flange. Grinder ring is pressed into flange for easy removal. See Figure 3.
3. Thread two screws into tapped back-off holes in flange and evenly tighten screws to back grinding ring out of pump housing.
4. Place large flat blade screwdriver into slot in shaft.
5. Bump impeller vane counter-clockwise with plastic hammer to loosen impeller and continue to unscrew impeller from shaft. See Figure 4.
6. Use wire brush and thoroughly clean any deposit from passage above grinder impeller and incavity for grinder ring. See Figure 5.
7. Replace new grinder impeller, use screwdriver in slot while turning on impeller, until hand tight, with screwdriver still in shaft slot bump with plastic hammer. See Figure 6.
8. Replace new grinder ring and plate. Use oil on ring for easy fit.
9. To provide proper alignment use three sections of an old $\frac{1}{2}$ " tape measure as shims 120 degree apart and then tighten bolts. **Be sure to pull screws down evenly, applying pressure on all three screws. DO NOT TIGHTEN ONE SCREW CLEAR DOWN BEFORE ADJUSTING OTHER SCREWS.** See Figure 7.
10. Replace holding screw and washer, use small amount of Loctite #271 screw. See Figure 8.
11. Bump set screw wrench with plastic hammer to tighten, working against small allen wrench or screwdriver in shredding ring.
12. Check freedom of rotation using finger on impeller vanes. Pump should turn free with slight drag due to seals. Use caution to avoid injury from shredding ring while turning grinding impeller.




FIG. 3




FIG. 4




FIG. 5

13. As a final check, measure distance from end of ring to bottom of impeller vanes. This should be $\frac{3}{32}$ " to $\frac{1}{8}$ ". If distance is only $\frac{1}{16}$ " or less it will indicate pump impeller has partially unscrewed when grinder impeller was removed. See Figures 9 and 10. If this is the case, pump case will have to be removed to tighten pump impeller. These steps will be given in the following instructions. In rare cases if the impeller is jammed so tight it can't be removed by the steps given it will be necessary to remove the motor housing so that the motor rotor can be gripped to break loose the grinder impeller. See Figure 11.




FIG. 6




FIG. 7




FIG. 8





FIG. 9



"PROPER SETTING OF GRINDER IMPELLER."
IMPELLER VANE TIPS EXTEND ABOUT 1/8"
BELOW BOTTOM OF SHREDDING RING.

FIG. 10

REPLACING LOWER SEAL

1. Use steps 1 through 5 for removing grinder ring and grinder impeller.
2. Before removing any other parts use a marking pen to mark joining parts so that they can be replaced in same position as removed. See Figure 12.
3. Remove oil fill plug slowly from seal chamber as pressure may have built up in this cavity, and pour out oil. See Figures 13 & 14.
4. Remove volute case bolts and pull off volute casing. Plastic hammer can be used to bump on casing discharge to loosen. Place gasket in oil to prevent drying out.
5. Insert large flat blade screwdriver in slot provided in pump shaft and hold impeller hub with Vise Grip Pliers. Turn impeller counter-clockwise to loosen. It may be necessary to bump pliers a sharp blow with plastic hammer to loosen impeller. See Figure 15. Turn counter-clockwise to loosen.
6. Use wire brush and putty knife and clean casting before removing seal.
7. Remove allen socket head screws from seal plate. See Figure 16.




FIG. 12




FIG. 13




FIG. 11




FIG. 14

8. Pry carbon portion of seal from shaft by using flat blade screwdrivers on each side of shaft. **DO NOT SCRATCH SHAFT.** It does not matter if carbon cracks as it may be replaced with new part. See Figure 17.
9. Remove ceramic seal face and rubber retaining boot by prying seal out with flat blade screwdrivers. (Seal can be pressed out with a screwdriver from the opposite side.) Be careful not to scratch bronze bushing. Damage to seal is not important, as a new part must be installed. See Figure 18.




FIG. 17




FIG. 15



FIG. 18




FIG. 16




FIG. 19

10. Thoroughly clean inside of seal chamber and pocket where new seal is to be installed. See Figure 19. Use rags and solvent cleaner.
11. Use care to avoid touching sealing faces with hands, use protective cardboard circle provided with seal, while handling. Use an artists brush to coat bottom outside portion of rubber retaining boot with conservative application of STP or equivalent lubrication to ease installation. See Figure 20.
12. Place seal in seal cavity loosely and using cardboard protector use both thumbs to press seal into seal plate. The cardboard protector can be moved about to insure seal is pressed in evenly. See Figure 21.
13. Wetting finger and touching center of cardboard protector will allow it to be easily removed.
14. Coat lower rubber shaft boot portion of carbon half of rotary seal with conservative application of STP or equivalent lubricant. Next immerse seal in small container of Myer Submersible Oil (small baby food jar recommended). See Figure 22. Firmly press seal on shaft using thumbs. Observe that carbon seal is firmly in contact with ceramic portion of seal, and that carbon portion has not slipped out of its metal holder. See Figure 23. Install spring for lower seal only. **NOTE:** Discard spring retaining ring provided with the seal, as a groove is machined in the back side of the bronze impeller to locate and retain this seal spring.
15. Replace impeller and tighten with vise grip pliers, holding shaft with large flat blade screwdriver.
16. File off any burrs made on impeller neck with vise grip pliers. See Figure 24.




FIG. 20




FIG. 21



FIG. 22




FIG. 23



FIG. 26




FIG. 24




FIG. 27




FIG. 25




FIG. 28

17. Clean casing thoroughly with wire brush and wash out with solvent. Be sure the discharge port and small weep hole in the volute case is clean and free of any deposits. See Figure 25.
18. Replace volute case being careful to have gasket in place. Line up with center marks made before dismantling pump. See Figure 26.
19. Replace grinder ring and impeller as described under "Replacing Grinder Ring & Grinder impeller".
20. Air test repaired pump with approximately 6 lbs. of air pressure using piping with pressure gauge and air valve stem. Submerge in water and after evacuating air from volute case observe for leaks, remove and dry off pump.
21. Refill seal chamber with Myers Submersible Oil. See Figure 27. Fill until oil is 3/4" below top of oil plug boss. See Figure 28.
22. Clean oil plug with wire brush, reapply teflon tape and reinstall oil plug.
23. In rare case when impeller is locked too tight to remove as described, it may be necessary to lift off the motor housing so that rotor can be held while impeller is removed.

REPLACING UPPER SEAL

To replace upper seal it is necessary to completely dismantle the pump. Usually if upper seal is out, the motor stator will be ruined with water, so it will also be necessary to be replaced.

1. Remove oil fill plugs slowly and drain oil from motor and seal chamber. See Figures 29, 30 and Figure 31.
2. Remove motor end cap screws and thread into tapped back-off holes to force cap from motor housing. See Figure 32.
3. Lift cap and remove lead from ground screw. See Figure 33.




FIG. 29



FIG. 30




FIG. 31

4. Cut off all motor leads $\frac{3}{4}$ " down from the connector on the stator side, this way the cap and cord assembly and the connectors can be checked for continuity. See Figures 34 and 35.
5. Remove socket type flat head screws from bearing cap and thread into tapped back-off holes to force cap from housing. See Figure 36.
6. Remove bolts from motor stator housing and lift off casting. **Please Note:** Bearing Housing contains two finger spring washers which may fall out of casting when removed. The red and the orange seal failure wires will pull out of hole in stator. See Figure 37.
7. The rotor is now exposed and the red and orange seal failure wires are exposed. Rotor can now be held for removing grinder impeller and pump impeller as described before.
8. To remove upper seal use snap ring pliers and remove snap ring that holds upper seal in place. See Figure 38.
9. After snap ring is removed, bump on end of shaft with plastic hammer to force shaft through upper seal and to push lower ball bearing from housing. See Figure 39.




FIG. 33




FIG. 34




FIG. 32



FIG. 35




FIG. 36




FIG. 39




FIG. 37




FIG. 40




FIG. 38




FIG. 41

10. Push old seal out of housing. Clean thoroughly and press in new seal seat. As described in the first section steps 8 thru 14.
11. Replace ball bearings if worn or rusted from water being in motor.
12. Use arbor press to push off bearings. Use flat steel bars to get under bearing. See Figure 40.
13. In replacing bearings always press on inner race of bearing.
14. Replace red and orange seal failure wires if necessary. Loosen nut in seal chamber to remove wire.
15. Put in new seal failure wires and adjust so that the probe portion of the seal leak wires are staggered, the end of the longest wire being up $\frac{1}{4}$ " from the machined face of the casting. See Figure 41. Position shorter lead above the first so probes do not touch. See drawing front cover. Retighten seal nut. Be sure rubber seal ring is in place to seal wire. See Figure 42.
16. Using fine picture hanging wire pull seal failure wire up through stator hole before replacing stator. See Figure 43. The stator is pressed into housing at the factory and is shipped as a unit. Do not try to replace stator in housing in the field, they must be replaced as a unit.




FIG. 42




FIG. 43




FIG. 44




FIG. 45





FIG. 46



FIGURE

DIAGRAM FOR PUMP CYCLE ON 24"
DIAMETER BASIN

FIG. 47

Bearing housing will be held off of stator housing approximately $\frac{1}{16}$ inch and will depress to touch stator housing when pushed downward. See Figures 44, 45 and 46.

18. Reassemble all parts as taken apart. BE SURE NEW "O" RINGS ARE IN PLACE BEFORE BOLTING PARTS TOGETHER. If necessary to replace cords use cap with cords potted in. In emergency, cut cord can be spliced and taped.

Reconnect all motor lead wires to power cord with pressure type insulated connectors. Crimp tight with crimping pliers that will not penetrate the insulation of the connector.

19. Reinstall cap and cord assembly. Run OHM Meter resistance test at this time to check windings and test for grounding. Test seals with air pressure as described earlier.
20. Fill motor chamber and seal chamber with Myers Submersible Oil. Fill top motor chamber to bottom of seal plug threads and fill seal chamber to within $\frac{3}{4}$ " of top of plug fill boss.


IMPORTANT — AFTER ALL ASSEMBLY AND REPLACEMENT OF PARTS BE SURE PUMP TURNS FREE BY HAND. PUMP MUST NOT BIND IN ANY POSITION OF ROTATION.

ELECTRICAL CONTROL BOX — All instructions and wiring diagrams for connecting pump to control box are included with the control box.


17. Using allen wrench or small screwdriver in bolt holes to hold parts in place, position upper bearing casting upside-down and run wires down thru holes in segmented casting. Next apply STP or equivalent to bearing cup liberally and insert the first finger spring washer flat side down. Apply more STP and insert second finger spring washer flatside down, to make paired finger washers. Apply STP again to hold washers in place when casting is turned over and installed on top of rotor.

MOTOR WIRING DIAGRAMS


NOTE: Probe test resistor is used on WGX20 UL explosion-proof only.




230 VOLT - SINGLE PHASE



200 OR 575 VOLT - THREE PHASE



230 VOLT - THREE PHASE



460 VOLT - THREE PHASE

CHECK LIST TO DETERMINE MOTOR TROUBLE

CHECKING FOR MOISTURE IN MOTOR —

Use ohmmeter and set on highest scale. Readings on the large power cord between any of the conductors red, black, white to green conductor or motor shell should be more than 500,000 ohms. Motor probably will run with a lower reading, but if pump is out of service and reading is below 500,000 ohms the motor housing and stator should be removed and baked in a drying oven at 220°F. to dry out winding. If winding cannot be dried out it must be replaced.

Both motor housing and stator must be replaced as a unit as stator is pressed in at the factory and cannot be removed in the field.

RESISTANCE OF WINDINGS — Every motor winding has a fixed resistance and winding must check close to the values given below to operate properly. This winding resistance also shows if motor is connected for voltage being used.

Use ohmmeter for this test and set on scale to read directly in ohms.

WINDING RESISTANCE VALUES IN OHMS

Motor Type & Voltage	Black To White Main Winding	Black To Red Start Winding	White To Red
----------------------	-----------------------------	----------------------------	--------------

Set OHM Meter to RX-1 and Zero Meter

Single Phase 208 Volts	1.27	6.25	7.52
Single Phase 230 Volts	1.56	7.84	9.40
Three Phase 200 Volts	2.91	2.91	2.91
Three Phase 230 Volts	3.15	3.15	3.15
Three Phase 460 Volts	12.6	12.6	12.6
Three Phase 575 Volts	29.6	29.6	29.6

FULL LOAD AMP READINGS FOR MOTORS

Motor Type	Volts	Amps	Locked Rotor Amps
Single Phase	208	15	50.0
Single Phase	230	12	41.0
Three Phase	200	9.5	30.0
Three Phase	230	8.4	27.5
Three Phase	460	4.2	15.6
Three Phase	575	3.3	13.0

If amp readings are higher than listed it indicates voltage may be higher or lower than normal or that pump grinder may be clogged with trash causing extra load on motor.

TROUBLE CHECK LIST

Troubles listed are generally caused by the pump. Other trouble can occur from faulty control box operation. These will be listed with the control box instructions.

CONDITION	PROBABLE CAUSE
Pump runs but does not pump liquid from basin.	<ol style="list-style-type: none"> 1. Pump impeller may be air locked, this occasionally occurs on a new installation. Remove pump and clean volute case weep hole and reinstall pump allowing 2 to 3 minutes for air to weep from pump. 2. Remove pump and guides from wet well, and test in 5 gallon bucket, after checking weep hole again. If pump still does not pump disassemble, check valve and check to insure that check valve flapper has not adhered to sealing face. This condition results from assembled basin units setting in the sun before installation. <p>NOTE: Check Valve bolts should have Loctite 242 or equivalent applied before reassembly of check valves.</p>
3. If pump will pump water from bucket, try in wet well again. If it still will not pump, the following problems may exist:	<ol style="list-style-type: none"> (A) Ball Valve — Gate Valve may be in off position (B) Discharge Piping obstructed (C) Valve at street or in main line may be off — Redundant Check Valve in backwards (D) Tap at force main obstructed — hole not drilled thru enough — pipes pushed into tee too far.

4. If pump has been installed for some time and does not pump, it may be clogged at grinder inlet.
5. Discharge head may be too high. Check elevation. Maximum pump head at zero flow is 105 feet. See Pump Curve.
6. If above checks do not locate trouble, motor rotor may be loose on shaft which allows motor to run but will not turn impeller or only at low RPM.

water is below lower weight, or lower weight may have dropped off, or mercury style float may have become trapped in the on position in basin — relocate float position or height in basin.

3. Grinder assembly may be partially clogged causing pump to operate at very reduced capacity.
4. Check valve may be clogged causing low pump flow. Gate valve or street valve may be in off position.
5. Pump may be air logged.

Red seal leakage.
Light, comes on at control box.

A dim glow may be present in seal light due to the nature of neon bulbs, this condition is normal. For full brightness comparison replace pump run lens with red seal leak lens, turn on pump and observe full brightness. If seal leak light does glow brightly, this indicates some water has leaked past the lower seal and has entered the seal chamber and made contact with the electrode probe. Pump must be removed from basin within approximately two (2) weeks for replacement of lower seal. This preventative repair will save an expensive motor.

Circuit breaker trips.

1. Repeat breaker by pushing clear down on handle then back to on position. If breaker trips again in few seconds it indicates excessive load probably caused by a short in the motor or control box. Check out instructions given with control box before pulling pump.
2. If this condition happens after an electrical storm, motor or control box may be damaged by lightning.
3. Resistance reading of the motor with lead wires disconnected from the control box can determine if trouble is in motor or control box.

Overload trips at control box and alarm buzzer or flashing red light comes on due to high water level in basin.

1. Push in on red reset button if single phase or push in on re-set plunger if three phase to reset overload. If overload trips again after short run, pump has some damage and must be removed from basin for checking.
2. Trouble may be from faulty component in control box. Always check control box before removing pump.
3. Trouble may be from clogged grinder causing motor to overload or could be from failed motor.

Pump is noisy and pump rate is low.

1. Grinder assembly may be partially clogged with some foreign objects causing noise and overload on the motor.
2. Grinder impeller may be rubbing on grinder ring due to bent shaft or misalignment.

Grease and solids have accumulated around pump and will not pump out of basin.

1. Water shut off level may be set to high or volume of pumping cycle may be too great allowing solids to settle out of suspension. Set pump shut off level at the pumps widest part where volute case mates with seal chamber — to 1" below. See Figure 47.

Yellow run light stays on continuously.

1. Indicates H-O-A switch may be in the hand position.
2. Level control switch may have failed causing pump to continue to operate when

Set water level control
(Float or weight) to following
approx. levels:

2 ft. dia. basin 12" - 14"

3 ft. dia. basin 6" - 8"

4 ft. dia. basin 6" - 7"


above pump shut off.

- Run pump on hand operation for several minutes with small amount of water running into basin to clean out solids and grease. This allows pump to break suction


and surge which will break up the solids. If level switch lower weight or float is set properly this condition generally will not occur.

- Where all type switches are installed trash may have accumulated around lower weight causing pump to turn off too soon. Clean trash from weight and suspension cable.

PERFORMANCE CURVE



DIMENSIONS



MYERS

LIMITED WARRANTY

GRINDERS, NON-CLOG SEWAGE and WASTEWATER PUMPS

F. E. MYERS warrants that its products are free from defects in material and workmanship for a period of twelve (12) months from the date of purchase or eighteen (18) months from the date of manufacture.

During the warranty period and subject to the conditions hereinafter set forth, **MYERS**, will repair or replace to the original user or consumer parts which prove defective due to defective materials or workmanship of **MYERS**. Contact your nearest authorized **MYERS** distributor or **MYERS** for warranty service. At all times, **MYERS** shall have and possess the sole right and option to determine whether to repair or replace defective equipment, parts or components..

Start up reports and electrical system schematics may be required to support warranty claims. Warranty effective only if **MYERS** supplied or authorized control panels are used.

LABOR, ETC. COSTS: **MYERS** shall IN NO EVENT be responsible or liable for the cost of field labor or other charges incurred by any customer in removing and/or reaffixing any **MYERS** product, part or component thereof.

THIS WARRANTY WILL NOT APPLY: (a) to defects or malfunctions resulting from failure to properly install, operate or maintain the unit in accordance with printed instructions provided; (b) to failures resulting from abuse, accident or negligence; (c) to normal maintenance services and the parts used in connection with such service; (d) to units which are not installed in accordance with applicable local codes, ordinances and good trade practices; or (e) if the unit is moved from its original installation location and (f) unit is used for purposes other than for what it was designed and manufactured.

RETURN OR REPLACED COMPONENTS: any item to be replaced under this Warranty must be returned to **MYERS** in Ashland, Ohio, or such other place as **MYERS** may designate, freight prepaid.

PRODUCT IMPROVEMENTS: **MYERS** reserves the right to change or improve its products or any portions thereof without being obligated to provide such a change or improvement for units sold and/or shipped prior to such a change or improvement.

WARRANTY EXCLUSIONS: **MYERS** MAKES NO EXPRESS OR IMPLIED WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. **MYERS** SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE.

Some states do not permit some or all of the above warranty limitations and, therefore, such limitations may not apply to you. No warranties or representations at any time made by any representatives of Myers shall vary or expand the provision hereof.

LIABILITY LIMITATION: IN NO EVENT SHALL **MYERS** BE LIABLE OR RESPONSIBLE FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES RESULTING FROM OR RELATED IN ANY MANNER TO ANY **MYERS** PRODUCT OR PARTS THEREOF. PERSONAL INJURY AND/OR PROPERTY DAMAGE MAY RESULT FROM IMPROPER INSTALLATION. **MYERS** DISCLAIMS ALL LIABILITY, INCLUDING LIABILITY UNDER THIS WARRANTY, FOR IMPROPER INSTALLATION -- **MYERS** RECOMMENDS INSTALLATION BY PROFESSIONALS.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

In the absence of suitable proof of this purchase date, the effective date of this warranty will be based upon the date of manufacture.

Myers®

Pentair Pump Group

F. E. Myers, 1101 Myers Parkway, Ashland, Ohio 44805-1969
419/289-1144, FAX: 419/289-6658, www.femyers.com