RZWS



FEATURES

- Patented StrataRoot™ baffles divert water to the root zone while adding strength to the unit
- Durable locking cap
- Pressure-compensating bubbler
- Built-in Hunter Swing Joint for direct installation to 1/2" PVC fitting
- Pre-assembled watering system for fast installation
- Warranty period: 2 years

OPERATING SPECIFICATIONS

- Bubbler flow rates: 0.25 or 0.50 GPM
- Recommended pressure range: 15 to 70 PSI

FACTORY INSTALLED OPTIONS

- Check valve
- Locking reclaimed purple cap

USER INSTALLED OPTIONS

- Fabric sleeve that helps prevent soil intrusion in sandy areas for 18" and 36" models (P/N RZWS-SLEEVE)
- Replacement cap for 18" and 36" models (P/N 913300SP)
- Locking reclaimed purple cap for 18" and 36" models (P/N 913301SP)
- Reclaimed water purple cap for 10" (P/N RZWS10-RCC)

RZB

The RZB is an accessory for small trees and shrubs that assists irrigation systems in delivering water to the roots.

- Solid mesh tube with perforated top to complement overhead or drip irrigation systems
- Allows oxygen and natural precipitation to reach the root zone
- Easy installation that directs overhead and drip irrigation to the root zone



Diameter: 2" Length: 9"



RZWS-10 Diameter: 2" Length: 10"

RZWS-18 Tube Diameter: 3" Cap Diameter: 4.75" Length: 18"

RZWS-36 Tube Diameter: 3" Diameter: 4.75" Length: 36"



Reclaimed models available Add -R to model number

ROOT ZONE WATERING SYSTEM - SPECIFICATION BUILDER: Order 1 + 2 + 3		
1 Model	2 Bubbler Flow Rate	3 Options
RZWS-10 = 10" root zone watering system	25 = 0.25 GPM	(blank) = No option
RZWS-18 = 18" root zone watering system	50 = 0.50 GPM	CV = Check valve
RZWS-36 = 36" root zone watering system	(blank) = No bubbler or swing joint	R = Reclaimed cap
		CV-R = Check valve with reclaimed cap

Examples:

RZWS-18 - 25 = 18" root zone watering system at 0.25 GPM

RZWS-10 - 50 - CV = 10" root zone watering system at 0.50 GPM, with check valve

RZWS-36 - 25 - CV-R = 36" root zone watering system at 0.25 GPM, with check valve and reclaimed cap

ADDITIONAL OPTIONS (SPECIFY SEPARATELY)

RZWS-SLEEVE = Field-installed sleeve made from filter fabric