






Company, Inc.

- 4 in 1 alternative replaces a ball valve + 2 tee fittings + drain valve
- Easily install, isolate, drain and replace any expansion tank
- Quickly connect entire system to the cold water feed



INSTALLATION IS AS EASY AS

Connect the supply feed to the tee pattern FIP connection.


Connect the expansion tank's standard $\frac{1}{2}$ " MIP Connection to the valve's FIP connection.

Connect the valve's MIP/SWT connection to the main system.



To Service - simply close the expansion tank isolation valve, connect a hose to the drain outlet and open the drain valve. The pressure in the tank will cause the contents to drain from the unit quickly and without spillage.

SIMPLIFY YOUR WORK



MAXIMIZE EVERY INSTALLATION WITH WEBSTONE INNOVATION