

**CSI MODEL 10164-L SAMPLER CONTROL CABLE
FOR USE WITH ISCO AND SIGMA AUTOSAMPLERS
INSTRUCTION MANUAL**

1/99

COPYRIGHT (c) 1998-1999 CAMPBELL SCIENTIFIC, INC.

WARRANTY AND ASSISTANCE

The **CSI MODEL 10164-L SAMPLER CONTROL CABLE** is warranted by CAMPBELL SCIENTIFIC, INC. to be free from defects in materials and workmanship under normal use and service for twelve (12) months from date of shipment unless specified otherwise. Batteries have no warranty. CAMPBELL SCIENTIFIC, INC.'s obligation under this warranty is limited to repairing or replacing (at CAMPBELL SCIENTIFIC, INC.'s option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CAMPBELL SCIENTIFIC, INC. CAMPBELL SCIENTIFIC, INC. will return such products by surface carrier prepaid. This warranty shall not apply to any CAMPBELL SCIENTIFIC, INC. products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CAMPBELL SCIENTIFIC, INC. is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 753-2342. After an applications engineer determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. CAMPBELL SCIENTIFIC's shipping address is:

CAMPBELL SCIENTIFIC, INC.

RMA# _____

815 West 1800 North
Logan, Utah 84321-1784

CAMPBELL SCIENTIFIC, INC. does not accept collect calls.

Non-warranty products returned for repair should be accompanied by a purchase order to cover the repair.



CAMPBELL SCIENTIFIC, INC.

815 W. 1800 N.
Logan, UT 84321-1784
USA
Phone (435) 753-2342
FAX (435) 750-9540
www.campbellsci.com

Campbell Scientific Canada Corp.
11564 -149th Street
Edmonton, Alberta T5M 1W7
CANADA
Phone (780) 454-2505
FAX (780) 454-2655

Campbell Scientific Ltd.
Campbell Park
80 Hathern Road
Shepshed, Loughborough
LE12 9GX, U.K.
Phone +44 (0) 1509 601141
FAX +44 (0) 1509 601091

CSI MODEL 10164-L SAMPLER CONTROL CABLE FOR USE WITH ISCO AND SIGMA AUTOSAMPLERS

The 10164-L sampler control cable enables a datalogger to trigger an Isco, American Sigma, or connector-compatible autosampler. Through this cable, the datalogger can inhibit the sampler from running its programmed sampling routine and sense and record when the sampler indicates that it has taken a sample. The following examples illustrate its use. Each of these functions are independent of the others and you may combine functions as desired. You should insulate and tuck out of the way any unused wires.

Trigger Sampler

<u>Wire color</u>	<u>CR10</u>	<u>21X</u>	<u>BDR320</u>
purple	G	Ground	GND
yellow	C2	Control 2	C2
red	12V	+12	12V
clear	G	Ground	GND

To trigger the sampler, pulse port 2 using a set of instructions such as follows:

Do (P86)

1: 42 Set Port 2 High

; Note: The 50 in the third parameter keeps the
; port high for 0.5 seconds. Some users have
; reported using a delay of 1 sec (100 in
; parameter 3) to ensure reliable triggering of
; the sampler.

Excitation with Delay (P22)

1: 1 Ex Channel
2: 0 Delay W/Ex (units = 0.01 sec)
3: 50 Delay After Ex (units = 0.01
sec)
4: 0 mV Excitation

Do (P86)

1: 52 Set Port 2 Low

For the CR10 and the 21X, you can also supply the trigger signal from switched excitation if no control ports are available. In this case, connect the yellow cable to the desired excitation channel (say E3) and pulse the channel using Instruction 22 as follows:

Excitation with Delay (P22)

1: 3 EX Chan (or the channel
you select)
2: 50 Delay w/EX (units=0.01sec)
3: 0 Delay after EX (units=0.01sec)
4: 2500 mV Excitation

Sense Sampler Event Markers

Pulse port method:

<u>Wire color</u>	<u>CR10</u>	<u>21X</u>	<u>BDR320</u>
purple	G	Ground	GND
orange	P1	Pulse 1	P1
clear	G	Ground	GND

To sense sampler events, use Instruction 3 with a configuration code of 0 (no configuration code or Reps are required for the BDR320):

Pulse (P3)

1: 1 Reps
2: 1 Pulse Input Chan
3: 0 High frequency
(configuration code)
4: 2 Loc [:EVENTS]
5: 1 Mult
6: 0 Offset

To record the events in the datalogger's final storage area, remember to totalize the events temporarily stored in Input Location 2 in this example.

CR10 control port interrupt method:

For the CR10, there is another useful method for sensing and recording sampler events. This method uses the control port 8/subroutine 98 interrupt feature of the CR10. Each time the sampler reports an event, the CR10 records the sample number with a time stamp in final storage. In this example, sampler events will show up as output arrays with an array ID of 400.

Wire color CR10

purple G
orange C8
clear G

CSI MODEL 10164-L SAMPLER CONTROL CABLE FOR USE WITH ISCO AND SIGMA AUTOSAMPLERS

CR10 Program (Subroutine 98 in Program Table 3)
* 3 Table 3 Subroutines

Technical details of cable design:

		<u>Wire color</u>	<u>Via</u>	<u>Connector pin</u>
1: Beginning of Subroutine (P85)				
1: 98	Subroutine Number	brown	direct	D
2: Z=Z+1 (P32)		green	direct	F
1: 10	Z Loc [Sample_No]	purple	direct	B
3: Do (P86)		yellow	solid state relay circuit	none (controls C)
1: 10	Set high Flag 0 (output flag)	red	solid state relay circuit	C
4: Set Active Storage Area (P80)		orange	20Kohm resistor	E
1: 1	Final Storage Area 1			
2: 400	Array ID or location	clear	cable shield	no connection
5: Real Time (P77)				
1: 1110	Year,Day,Hour-Minute			
6: Sample (P70)				
1: 1	Reps			
2: 10	Loc [Sample_No]			
7: End (P95) ;of Subroutine Number 98				

End Table 3

Inhibit Sampler's Program

<u>Wire color</u>	<u>CR10</u>	<u>21X</u>	<u>BDR320</u>
purple	G	Ground	GND
(Isco) green	C1	Control 1	C1
(Sigma) brown	C1	Control 1	C1
clear	G	Ground	GND

To *inhibit* an Isco sampler from running its own program, set control port 1 low using a program control instruction such as Instruction 86. To allow the sampler to run its program, set it high.

NOTE: The logic for Sigma samplers is just the opposite. A high signal inhibits the sampler.

Example for inhibiting an Isco sampler's program:

Do (P86)
1: 51 Set Port 1 low ;(41 would set it high)